
# 7. Parts Catalog

# **How To Use This Parts Catalog**

- SIMILAR ASSEMBLIES: If two assemblies contain a majority of identical parts, they are shown on the same list. Common parts are shown by one index number. Parts peculiar to one or the other of the assemblies are listed separately and identified by description.
- AR: (As Required) in the Units column indicates that the quantity is not the same for all machines.
- CC: (Color Code) in the Description column indicates the part is identified by a color marking on the part.
- NS: (Not Shown) in the Asm-Index column indicates that the part is procurable but is not pictured in the illustration.
- PP: (Parts Packet) in the Description column indicates the part is contained in a parts packet.

#### **Printer Serial Label**


Look at the printer serial label to identify the printer you are working on. There are two service levels of Optra T printers. Some printers are at a service level B as indicated by the B on the label.



Use the Model Name/Type table to identify model specific replacement FRUs. The parts catalog uses the **Type** last three digits to identify model specific FRUs.

Model Name	Туре
Optra T 610	4069-010
Optra T 610n	4069-01n
Optra T 612	4069-212
Optra T 612n	4069-21n
Optra T 614	4069-414
Optra T 614	4069-41b
Optra T 614n	4069-41e
Optra T 614nl	4069-411
Optra T 614n	4069-41n
Optra T 616	4069-616
Optra T 616n	4069-61n
Optra T 23v	4069-23v
Optra T 23e	4069-23e


# **Assembly 1: Covers**



Asm- Index	Part Number	Units	Description
1-1	99A1512	1	Cover Assembly, Redrive Cap
1-2	99A1508	1	Cover, Fuser Wick Assembly
1-3	99A1506	1	Cover Asm, Laser Assembly 010/212/23v/ 23e
1-3	99A1507	1	Cover Asm, Laser 500 Output 414/616/41b/ 41e/41l
NS		6	Screw, Laser Cover PP 99A0263
1-4	99A1593	1	Cable, Smart Cartridge
1-5	99A0816	1	Contact, Smart Cartridge Ground
1-6	99A0815	2	Contact, Smart Cartridge
1-7	99A1595	1	Cover, Smart Cartridge Contact
1-8	99A0834	1	Plunger, Overstress Smart Cartridge
1-9		2	Screws, Contact Mounting PP 99A0263
1-10	99A1524	1	Cartridge Load Spring
1-11	99A1775	1	Kit, Upper Front Cover with Labels
NS		5	Screw, Upper Front Cvr Mtg PP 99A0263
1-12	99A1503	1	Hinge, Upper Front Cover
1-13	99A1504	1	Cover, RIght Side 010/212/23v/23e
1-13	99A1505	1	Cover, Right Side 414/616/41b/41e/41l
NS		3	Screw, Right Side Cvr Mtg PP 99A0263

4069-XXX


# **Assembly 1: Covers (continued)**



Asm- Index	Part Number	Units	Description
1-14	99A0007	1	Label, TLI/ID/Serial No Blank
1-15	99A1502	1	Latch, Upper Cover
1-16	99A0004	1	Spring, Latch
1-17	99A1511	1	Cover Assembly, Lower Front
1-18	99A1501	1	Operator Panel Assembly
1-19	99A1577	1	Switch, Cover Open w/Operator Panel Cable Assembly
1-20	99A1594	1	Retainer, Cable
1-21	99A1587	1	Support, Paper
NS		5	Screw, Left Side Cvr Mtg PP 99A0263
1-22	99A1509	1	Cover, Left Door 010/23v/23e
1-22	99A1510	1	Cover, Left Door 414/616/212/41b/41e/41I
NS	99A0577	1	Cable Tie

4069-XXX


# Assembly 2: Frame



Asm- Index	Part Number	Units	Description
2-1	99A1643	1	Shroud, Fan 250 010/01n/23v/23e
2-1	99A1592	1	Shroud, Fan 500 212/414/616/41b/41e/41l/ 21n/61n
2-2	99A0803	1	Fan, Main
2-3	99A0138	1	Sensor, Standard Bin Level 212/414/616/41b/ 41e/41l/21n/61n/23v/23e
2-4	99A1580	1	Flag, Output Paper Level 414/616/41b/41e/ 41l/61n
2-4	99A1613	1	Flag, Output Paper Level 212/21n/23v/23e
2-5	99A1879	1	Bracket, Level Sensor 212/414/616/21n/41b/ 41e/41l/61n
2-6	99A1515	1	Duct, 250 Left Stacker 010/212/01n/21n/23v/ 23e
2-6	99A1516	1	Duct, 500 Left Stacker 414/616/41b/41e/41l/ 61n
2-7	99A0867	1	Duct, Main Body
2-8	99A1832	1	Guide, Extension 500 Input 212/414/616/41b/ 41e/41I
2-9	99A1662	1	Support, Left Lower Stacker
2-10	99A0113	1	Pan, Drip ITC
2-11	99A1924	2	Spring, Cartridge Hold Down
2-13	99A1519	1	Extension, 500 Input 212/414/616/41b/41l/ 41e/21n/61n
2-14	99A0058	4	Pad, Machine Mounting
2-15	99A1588	1	Transfer Plate Assembly
2-16	99A1663	1	Support, Right Stacker Plate 0ln/0l0/212/2ln
2-16	99A1968	1	Support, Right Stacker Plate 4l4/4lb/4lc/4lL/6l6/6ln
2-17	99A1535	1	Right Sideframe
2-18	99A0049	1	Fan, Auxiliary 616/61n
2-19	99A1518	1	Frame Extension, Right 500 Internal 212/414/61621n/61n/41b/41e/41l
2-20	99A0028	1	Spring, Tray Bias
2-21		1	Contact Kit PP 99A0585
		3	o Contact, Doctor Blade/TAR/Developer Roll
		1	o Contact, PC Drum
		1	o Contact, Charge Roll
		4	o Block, Contact Mounting
		5	o Screw, Contact Mounting

4069-XXX


# **Assembly 2: Frame (continued)**



Asm- Index	Part Number	Units	Description
2-22	99A0466	1	Sensor, Toner Cartridge Level
2-23	99A0039	2	Roller, Developer Support
2-24	99A0026	1	Tray Bias Arm Assembly
2-25	99A1522	1	Pan, Center Assembly
2-26	99A1525	1	Deflector, Upper PF
2-27	99A1850	1	Deflector, Inner 2l2/4l4/6l6/2ln/6ln/4lb/4le/4lL
2-27	99A0055	1	Deflector, Inner 0l0/0ln/23v/23e
2-28	99A1897	1	Frame, EP Module service level B
2-28	99A1833	1	Frame, EP Module 010/212/414/616/01n/21n/61n
2-29	99A0053	1	Sensor, Input
2-30	99A1517	1	Frame Extension, Left 500 Internal 212/414/616/21n/61n/41b/41e/41l
2-31	99A0549	1	Shield, ESD Assembly with label
2-32	99A0063	1	Spring, PA Switch Activate
2-33	99A1514	1	Left Side Frame
2-34	99A0128	1	Board, Input Tray (ITC)
2-35	99A1896	1	Guard, Gear
2-36	99A0899	1	Pan, Motor Drip
2-37	99A0567	1	Link, Gear Release 010/212/414/616/01n/ 21n/61n/41b/41e/41I
2-38	99A0556	1	Spring, Counterbalance
NS		17	Screw PP 99A0263
NS	99A1546	1	Shield, Gear
NS	99A1596	1	Contact, LSF Ground
NS	99A1538	1	Contact, RSF Ground
NS	99A1540	4	Nutplate, Frame 212/414/616/21n/41b/41e/ 41l/61n
NS	99A1541	1	Spring, Duplex Ground 212/414/616/21n/41b/ 41e/41l/61n/23v/23e

4069-XXX


# Assembly 3: Printhead



Asm- Index	Part Number	Units	Description
3-1	99A1526	1	Printhead Assembly, 010/01n
3-1	99A1527	1	Printhead Assembly, 212/21n/23v/23e
3-1	99A1528	1	Printhead Assembly, 414
3-1	99A1867	1	Printhead Assembly, 41b/41e/41l
3-1	99A1873	1	Printhead Assembly, 616/61n
NS		3	Screw, Printhead Mounting PP 99A0263


4069-XXX

# **Assembly 4: Paper Feed (Autocompensator)**



Asm- Index	Part Number	Units	Description
4-1	99A0060	1	Sensor, Paper Out Internal Tray
4-2	99A1056	1	Pick Arm Assembly (250) 010/01n/23v/23e
4-2	99A1530	1	Pick Arm Assembly (500) 212/414/616/21n/ 41b/41l/41e/61n
4-3	56P1228	1	Spring Arm Bellcrank
4-4	99A1927	1	Spring, Bellcrank Internal 250 010/01n/23v/ 23e
4-4	99A1930	1	Spring, Bellcranck Internal 500 212/414/616/ 41b/41l/41e/61n
4-5	99A0070	2	Pick Rolls
4-6	99A1616	1	Flag, Paper Out 500 Tray 212/414/616/21n/ 41b/41l/41e/61n
4-6	99A1609	1	Flag, Paper Out 250 Internal Tray 010/01n/ 23v/23e
NS		1	Screw, Hanger PP 99A0263


# Assembly 5: Paper Feed - Multipurpose Unit



Asm- Index	Part Number	Units	Description
5-1	99A0075	1	Screw, Socket Set M4X5 mm
5-2	99A0071	1	Arm Assembly, MPT
5-3	99A0076	1	Pick Roll Assembly
5-4	99A0081	1	Spring Assembly, Separator
5-5	99A0083	1	MPT Pad Assembly Kit o Restraint Pad o MPT Pad Assembly
5-6	99A1608	1	Deflector Assembly, MPT
5-7	99A1531	1	Deflector, Lower
5-8		2	Screw, Lower Deflector Mounting 8 mm PP 99A0263
5-8		2	Screw, Lower Deflector Mounting 12mm PP 99A0263
5-9	99A0084	1	Flag, MPT Paper Out
5-10	99A0082	1	Plate Assembly, MPT
5-11	99A0078	1	Sensor, MPT Paper Out
5-12	99A0073	2	Screw, Damper
5-13		1	Screw, Frame Mounting PP 99A0263
NS		2	Clip, Pick Roll Shaft PP 99A0267
5-14	99A2438	1	Solenoid, MPT
5-15	99A0074	2	Bushing, Pick Roll Shaft

4069-XXX


# **Assembly 6: Paper Feed - Alignment**



Asm- Index	Part Number	Units	Description
6-1	99A0089	1	Alignment Assembly Paper Feed
6-2	99A1953	1	Screw, Reference Ground Clip
6-3	99A0490	1	Clip, Reference Ground
6-4	99A0492	1	Screw, Paper Reference Adjustment
6-5	99A0565	1	Washer, Reference Adjustment
6-6	99A0566	1	Nut, Paper Reference Adjustment
6-7	99A0559	1	Lever, Bellcrank Release
NS		2	Screw, Alignment Asm Mtg PP 99A0263


4069-XXX

# Assembly 7: Paper Feed - Output




Asm- Index	Part Number	Units	Description
7-1	99A1586	1	Redrive Assembly, Inner 250 010/01n/23v/ 23e
7-1	99A1604	1	Redrive Assembly, 212
7-1	99A1533	1	Redrive Assembly, Inner 500 414/616/61n/ 41b/41l/41e/21n
7-2	99A1644	1	Door Assembly, Redrive 250 010/212/21n/ 23v/23e
7-2	99A1534	1	Door Assembly, Redrive 500 414/616/41b/41l/ 41e/61n
NS	99A0104	1	Spring, Upper Diverter
NS	99A1857	1	Deflector, Upper Redrive
NS		2	Screw, SEMS-Duplex Path PP 99A0263

4069-XXX
Assembly 8: Integrated Paper Tray - 250 Sheet




Asm- Index	Part Number	Units	Description
8-1	99A1536	1	Tray, Integrated 250 Sheet 010/01n/23v/23e
8-2	99A1601	1	Latch, Back Restraint
8-3	99A0120	2	Restraint Pad
8-4	99A1894	1	Restraint, Side 250 Sheet Tray
8-5	99A0119	4	Wear Strips
8-6	99A1812	1	Label, Tray Option Number
8-7	99A0121	1	Clip, 250 Tray Wear
8-8	99A0126	4	Finger, Autosize
8-9	99A0124	1	Plate, Snap-In
8-10	99A0127	1	Slider, Autosize 250
8-11	99A1952	1	Label, Paper Size
8-12	99A0893	1	Restraint, Back 250 Sheet Tray
8-13	99A1537	1	Knob, Paper Size

4069-XXX
Assembly 9: Integrated Paper Tray - 500 Sheet




Asm- Index	Part Number	Units	Description
9-1	99A1601	1	Latch, Back Restraint
9-2	99A1576	1	Tray Assembly 500 Sheet 212/414/616/21n/ 41b/41l/41e/61n
9-3	99A1895	1	Restraint, Side
9-4	99A0292	4	Strip, Wear
9-5	99A1812	1	Label, Tray Option Number
9-6	99A1750	1	Plate, 500 Tray Wear
9-7	99A0126	3	Finger, Autosize
9-8	99A0124	1	Plate, Snap-in
9-9	99A1952	1	Label, Paper Size
9-10	99A1537	1	Knob, Paper Size
9-11	99A1582	1	Slider, Autosize 500
9-12	99A0120	2	Pad, Restraint
9-13	99A1602	1	Restraint, Back

4069-XXX Assembly 10: Main Drive




Asm- Index	Part Number	Units	Description
10-1	99A1543	1	Gearbox, w/Motor 010/212/01n/21n/23v/23e
10-1	99A0129	1	Gearbox, w/Motor 414/41b/41l/41e
10-1	99A0801	1	Gearbox, w/Motor 616/61n
10-2	99A0134	1	Shaft, Power Take Off 010/01n/23v/23e
10-2	99A1569	1	Shaft, Power Take Off 500 212/414/616/21n/ 41b/41l/41e/61n
10-3	99A0275	1	Spring, Power Takeoff Shaft
10-4	99A0954	1	Gear, Bevel with Grease Packet
NS		4	Screw, Gearbox Mounting PP 99A0263
NS		3	Screw, Motor Mounting PP 99A0263
NS	99A0260	2	Clip, Cable

4069-XXX
Assembly 11: Developer Drive




Asm- Index	Part Number	Units	Description
11-1	99A1544	1	Developer Drive Assembly
11-2	99A0564	1	Coupler, Gear #55
11-3	99A0136	1	Shaft, Developer Drive
11-4		1	Screw, Developer Drive Ground PP 99A0263
11-5		2	Screw, Developer Drive Mtg PP 99A0263

4069-XXX Assembly 12: Hot Roll Fuser



Asm- Index	Part Number	Units	Description
12-1	99A1977	1	Fuser Assembly w/115V 875W Lamp 414/ 616/41b/41l/41n/61n
12-1	99A1585	1	Fuser Assembly w/220V 875W Lamp 414/ 616/41b/41l/41n/61n
12-1	99A1969	1	Fuser Assembly w115V 550W Lamp 010/212/ 01n/21n/23v/23e
12-1	99A1661	1	Fuser Assembly w220V 550W Lamp 010/212/ 01n/21n
12-2	99A0725	1	Wiper Assembly, Wet
12-3	99A1603	1	Cover, Fuser Assembly with Thermistor, Thermal Fuse, and LH & RH Fuser Lamp Contact Assemblies
12-4		4	Screw, Contact Assembly PP 99A0263
12-5	99A1631	1	Exit Roll Assembly
12-6	99A1520	1	Gear, Upper Redrive
12-7	99A0833	1	Detack Assembly
12-8	99A1521	1	Hot Roll, 010/212/41b/41e/41l/21n/01n/23v/ 23e
12-8	99A1549	1	Hot Roll, 414/616/61n
12-9	99A0159	2	Spacer, BUR 010/212/01n/21n/23v/23e
12-10	99A1621	2	Bearing, BUR
12-11	99A0173	1	Solenoid Assembly, Envelope Conditioner
12-12		1	Screw, Solenoid Mounting PP 99A0263
12-13		1	Screw, Board Cover Mounting PP 99A0263
12-14	99A0160	1	Backup Roll, 22 mm 010/212/41b/41e/41l/ 01n/21n/23v/23e
12-14	99A0158	1	Backup Roll, CBM 28 mm 414/616/61n
12-15	99A1598	1	Shield, Fuser Board
12-16	99A0144	2	Retainer, Backup Roll Bearing
12-17	99A1553	1	Board Assembly, Fuser 010/212/414/616/01n/ 21n/61n/23v/23e
12-17	99A1868	1	Board Assembly, Fuser 41b/41e/41l
12-18	99A1649	2	Screw, Fuser Mounting
12-19	99A1902	2	Standoff, Fuser Control Board
12-20	99A0919	1	Standoff, Fuser Control Board


4069-XXX
Assembly 12: Hot Roll Fuser (continued)



Asm- Index	Part Number	Units	Description
12-21		2	Screw, Fuser Cover Assembly PP 99A0263
12-22	99A0142	2	Retainer, Hot Roll Bearing
12-23	99A0150	2	Bushing, Hot Roll
12-24	99A0143	2	Bearing, Hot Roll
12-25	99A1554	1	Fuser Cable, AC
12-26	99A1600	2	Bellcrank, Backup Roll 414/616/61n
12-26	99A1659	2	Bellcrank, Backup Roll 010/212/41b/41e/41l/ 21n/01n/23v/23e
12-27	99A1591	1	Guide, Fuser Entry
12-28		2	Retainer, Backup Roll Bellcrank PP 99A0267
12-29	99A0410	2	Spring, Backup Roll Bellcrank
12-30	99A1648	1	Fuser Cable, DC
12-31	99A1597	1	Clamp, Fuser Cable AC/DC
12-32	99A0157	1	Gear, Hot Roll
12-33	99A0148	1	Gear, Idler
12-34	99A0297	1	Link, Solenoid
12-35	99A1651	1	Sensor, Narrow Media
12-36	99A1551	1	Sensor, Exit
12-37	99A0897	2	Spring, Redrive Idler
12-38	99A0167	2	Roller, Redrive Idler
12-39	99A1550	1	Guide Assembly, Lower Exit
12-40	99A1547	1	Lamp, 115V 875W CC Gold
12-40	99A1639	1	Lamp, 115V 550W CC Green
12-40	99A1548	1	Lamp, 220V 875W CC Silver
12-40	99A1642	1	Lamp, 220V 550W CC Brown
NS	99A1658	1	Cover, Fuser Wiper Cavity
NS		7	Screw, Hanger PP 99A0263
NS	99A0145	3	Clip, Fuse Mounting
NS	99A1599	1	Tray, Fuser AC Connector


4069-XXX

# Assembly 13: Transfer



Asm- Index	Part Number	Units	Description
13-1	99A1015	1	Transfer Roll Assembly
13-2	99A0349	1	Arm, Transfer Roll Assembly Right
13-3	99A0184	1	Spring, Transfer Roll Right
13-4	99A0186	1	Erase Lamp Assembly Kit 010/212/414/616/ 01n/21n/61n o Lamp, Erase Assembly o Lens, Erase Lamp
13-5	99A0185	1	Shaft, Transfer Pivot
13-6	99A0181	1	Spring, Transfer Roll Left
13-7	99A1578	1	Arm, Transfer Roll Left
NS		1	Retainer, Pivot Shaft PP 99A0267


4069-XXX Assembly 14: Charging



Asm- Index	Part Number	Units	Description
14-1	99A0512	1	Link Assembly, Charge Left Kit
14-2	99A0513	1	Link Assembly, Charge Right Kit
14-3	99A1017	1	Roll Assembly, Charge
14-4	99A1555	1	Bushing, Charge Roll
NS		1	Screw, Charge Roll PP 99A0263


4069-XXX

## **Assembly 15: Electronics**




Asm- Index	Part Number	Units	Description
15-1	99A1869	1	Engine Board Assembly 010/01n
15-1	99A1871	1	Engine Board Assembly 212/21n/23v/23e
15-1	99A1923	1	Engine Board Assembly 414/41b/41e/41l
15-1	99A1878	1	Engine Board Assembly 616/61n
15-2	1342514	1	Power Cord Set, 8 ft U.S., Canada (LV), Nicaragua, Venezuela, Peru (LV), Bolivia (HV), Colombia, Costa Rica, Ecuador, El Salvador, Guatemala, Honduras, Mexico, Panama
15-2	43H5248	1	Power Cord Set, 8 ft U.S., Canada (LV), Nicaragua, Venezuela, Peru (LV), Bolivia, Colombia, Costa Rica, Ecuador, El Salvador, Guatemala, Honduras, Mexico, Panama 414/41n/616/61n
15-2	1339538	1	Europe, 6 ft. Paraguay, Uruguay
15-2	1342536	1	Power Cord Set, 6 ft APG (LV)
15-2	1339537	1	Power Cord Set, 8 ft U.K., Ireland
15-2	1339539	1	Power Cord Set, 6 ft Israel
15-2	1339540	1	Power Cord Set, 6 ft Switzerland
15-2	1339541	1	Power Cord Set, 6 ft South Africa
15-2	1339546	1	Power Cord Set, 6 ft Two-Prong Argentina (HV)
15-2	1342534	1	Power Cord Set, 8 ft Chile (HV)
15-2	1339543	1	Power Cord Set, 8 ft Denmark
15-2	1339542	1	Power Cord Set, 6 ft Italy
15-2	1374067	1	Power Cord Set, 8 ft Peru (HV)
15-2	1339544	1	Power Cord Set, 8 ft Straight Argentina (HV)
15-2	1339545	1	Power Cord Set, 8 ft Right Angle Argentina (HV)
15-2	1342530	1	Power Cord Set - Brazil
15-3	99A0215	1	Fuse, 110 V ac LVPS
15-3	99A0205	1	Fuse, 220 V ac

# 4069-XXX Assembly 15: Electronics (continued)




Asm- Index	Part Number	Units	Description
15-4	99A1822	1	LVPS, 110 V ac 010/212/01n/21n/23v/23e
15-4	99A0214	1	LVPS, 110 V ac 616/61n
15-4	99A1640	1	LVPS, 220 V ac 010/212/01n/21n/23v/23e
15-4	99A1944	1	LVPS, 220 V ac 616/61n
15-4	99A1875	1	LVPS, 110 V ac 41l/41b/41e/414
15-4	99A1943	1	LVPS, 220 V ac 41l/41b/41e/414
15-5		1	Screw, HVPS Mounting PP 99A0263
15-6		1	Screw, Engine Bd Mounting Top PP 99A0263
15-7		o to <mark>"Pr</mark> i	neck the printer service level before replacing inter Serial Label" on page 7-2 to identify the FRU.
	99A1823 Hig	jh Voltag	e Power Supply 010/212/414/616/01n/21n/61n
	99A1863 Hig 23v/23e	gh Voltag	e Power Supply (all service level B printers)/
15-8	99A1617	1	Interconnect Board Assembly 212/414/616/41b/41l/41n/21n/61n o 2 Slot with shield
15-8	99A1581	1	Interconnect Board Assembly o 1 Slot with shield/23v/23e
15-8	99A1607	1	Interconnect Board Assembly 010/01n o 1 Slot with shield
15-9		2	Screw, Int Board Mounting PP 99A0263
15-9		1	Screw, Int Board Shield Ground PP 99A0263
15-9		2	Screw, Int Shield Mounting PP 99A0263
15-9		3	Screw, Int Shield Mounting PP 99A0263
15-10		2	Screw, Controller Bd Mounting Front PP 99A0263
15-11	99A0426	2	Screw, Parallel Connector Mounting
15-12		2	Screw, Controller Bd Mounting Back PP 99A0263

4069-XXX
Assembly 15: Electronics (continued)




Asm- Index	Part Number	Units	Description
15-13	99A1954	1	Controller Board Assembly 010
15-13	99A1955	1	Controller Board Assembly 212/23v
15-13	99A1956	1	Controller Board Assembly 414/41b
15-13	99A1957	1	Controller Board Assembly 616
15-13	99A1958	1	Controller Board Assembly 01n
15-13	99A1959	1	Controller Board Assembly 23e/21n
15-13	99A1960	1	Controller Board Assembly 41n/41l/41e/61n
15-14		2	Screw, Engine Bd Mtg Bottom PP 99A0263
15-14		2	Screw, Engine Bd Mtg Front PP 99A0263
15-14		2	Screw, Engine Bd Mtg Top PP 99A0263
NS	99A1612	1	Cable, Deflector
NS	99A0346	1	Clip, EMC Six Finger

4069-XXX
Assembly 15: Electronics (continued)



Asm- Index	Part Number	Units	Description
15-15	99A0408	1	Cover, INA Flat (Blank)
15-16		6	Screw, INA Cover Mounting PP 99A0263
15-16		4	Screw, INA Cover Mounting PP 99A0263
15-16		2	Screw, INA Cover Mounting PP 99A0263
15-17	99A1566	1	Engine Board Shield Assembly
15-18	99A1570	1	Shield, Inner Assembly, 1 slot 010/01n/23v/ 23e
		1	o Cover, INA Blank
15-18	99A1571	1	Shield, Inner Assembly, 2 slot 212/414/616/ 21n/41b/41l/41e/61n
		2	o Cover, INA Blank
15-19	99A0207	1	Shield, Outer 1 slot 010/01n/23v/23e
15-19	99A0206	1	Shield, Outer 2 slot 212/414/616/21n/41b/41l/ 41e/61n
15-20		4	Screw, Outer Shield Mounting PP 99A0263
15-20		6	Screw, Outer Shield Mounting PP 99A0263
15-21		1	Screw, Eng/Controller Mtg Ground PP 99A0263
NS		1	Screw, Eng/Int Shield Ground PP 99A0263
NS		2	Screw, Controller/Int Ground PP 99A0263
NS		2	Screw, Int/Pan Mounting PP 99A0263
NS		1	Screw, Eng/Int Ground PP 99A0263
NS	99A0260	1	Clip, Cable
NS		2	Screw, Cable Clip PP 99A0263
NS	99A1611	1	Shield, Ethernet Blank
NS	99A1610	1	Shield, Serial Blank


4069-XXX
Assembly 15: Electronics (continued)



7-46 Service Manual


Asm- Index	Part Number	Units	Description
15-22	99A0138	1	Sensor, Standard Bin Level
15-23	99A0803	1	Fan, Main
15-24	99A0255	1	Cable, Main Drive Motor
15-25	99A1543	1	Gearbox, w/Motor 010/212/01n/21n/23v/23e
15-25	99A0129	1	Gearbox, w/Motor 414/41b/41l/41n
15-25	99A0801	1	Gearbox, w/Motor 616/61n
15-26	99A0256	1	Cable, Integrated Tray
15-27	99A0128	1	Board, Input Tray (ITC)
15-28	99A1632	1	Cable, Auto Connect Bottom
15-29	99A0257	1	Cable, Auto Connect Top 212/414/616/21n/ 41b/41l/41e/61n/23v/23e

4069-XXX
Assembly 15: Electronics (continued)




Asm- Index	Part Number	Units	Description
15-30	99A0049	1	Fan, Auxiliary 414/616
15-31	99A0466	1	Sensor, Toner Cartridge Level
15-32	99A1593	1	Cable, Smart Cartridge
15-33	99A1501	1	Operator Panel Assembly
15-34	99A1577	1	Switch, Cover Open w/Operator Panel Cable Assembly
15-35	99A0053	1	Sensor, Input
15-36	99A0078	1	Sensor, MPT Paper Out
15-37	99A2438	1	MPT Solenoid
15-38	99A0186	1	Erase Lamp Assembly 010/212/414/616/0ln/6ln
15-39	99A0576	1	Cable, Front Harness
15-40	99A0815	2	Contacts, Smart Cartridge

4069-XXX
Assembly 15: Electronics (continued)



Asm- Index	Part Number	Units	Description
15-41	99A1526	1	Printhead Assembly 010/01n
15-41	99A1527	1	Printhead Assembly 212/21n
15-41	99A1528	1	Printhead Assembly 414
15-41	99A1873	1	Printhead Assembly, 616/61n
15-41	99A1867	1	Printhead Assembly, 41b/41e/41l
15-42	99A0889	1	Cable, Laser
15-43	99A1573	1	Cable, Fuser DC EP Autoconnect to Engine Board
15-44	99A0173	1	Solenoid Assembly, Envelope Conditioner
15-45	99A1553	1	Board Assembly
15-46	99A1551	1	Sensor, Exit
15-47	99A1603	1	Cover, Fuser Assembly with Thermistor, Thermal Fuse and RH Fuser Lamp Contact Assembly
15-48	99A1648	1	Cable, DC EP Autoconnect to Fuser Board
15-49	99A1651	1	Sensor, Narrow Media
15-50	99A1554	1	Cable, AC EP Autoconnect to Fuser Cover
15-51	99A1575	1	Cable, Fuser AC EP Autoconnect to LVPS
15-52	99A0247	1	Cable, Hysnc
15-53	99A0250	1	Cable, Mirror Motor
NS	99A1612	1	Cable, Deflector


4069-XXX Assembly 16: 250 Sheet Tray



7-52 Service Manual

Asm- Index	Part Number	Units	Description
16-1		3	Screw, Option Board Mounting PP 99A0263
16-2	99A1967	1	Board, Option Tray
16-3	99A0627	1	Jumper, 2-pin
16-4		1	Screw, Switch Activate Spring Mounting PP 99A0263
16-5	99A0063	1	Spring, Switch Activate
16-6	99A0445	1	Stud Assembly, 250 Frame
16-7	99A0448	1	Arm, Paper Out 250
16-8		3	Screw, Auto Comp Mounting PP 99A0263
16-9	99A1054	1	Pick Arm Assembly
16-10	99A0277	1	Wear Plate, Pass Thru 250 Tray
16-11		2	Screw, Wear Plate Mounting PP 99A0263
16-12	99A0276	1	Roll Assembly, Drive 500 Dual
16-13	99A0451	1	Roller, Skewed Backup
16-14	99A0282	1	Cable, 250 Tray Option
16-15	99A0450	1	Retainer, Roller
16-16	99A0350	1	Sensor, Paper Low
16-17	99A0679	2	Bracket, 250 Frame Retention
16-18		4	Washer, Bracket 250 Frame Retention Mounting PP 99A0677
16-19		4	Screw, Bracket 250 Frame Retention Mounting PP 99A0263


4069-XXX
Assembly 16: 250 Sheet Tray (continued)



7-54 Service Manual


Asm- Index	Part Number	Units	Description
16-20	99A0070	2	Roll Assembly, Pick
NS	99A0438	2	Bushing, Drive Roll
16-21	99A1638	1	Base, 250 Option
16-22	99A0026	1	Tray Bias Arm Assembly
16-23	99A0419	1	Spring, Tray Bias
16-24	99A0058	4	Pad, Machine Mounting
16-25	99A0288	1	Sensor, Option Pass Thru
16-26	99A1666	1	Label, Options
16-27	99A0272	1	Shaft, 250 Drive
16-28	99A0275	1	Spring, Power Takeoff
NS	99A0278	1	Bellcrank, Roller Release
16-29	99A0280	1	Bushing, Drive Shaft Low
16-30	99A0274	1	Gear, Feed Roll
16-31	99A0273	1	Gear, Bevel
16-32	99A0279	1	Bearing, Drive Shaft
16-33	99A0281	1	Cable, 250 Auto Connect Option
NS	99A1929	1	Spring, Bellcrank 250 Tray Option

4069-XXX
Assembly 16: 250 Sheet Tray (continued)




Asm- Index	Part Number	Units	Description
16-34	99A1601	1	Latch, Back Restraint
16-35	99A0120	2	Restraint Pad
16-36	99A1536	1	Tray Assembly, 250 Sheet Option
16-37	99A1894	1	Restraint, Side 250 Sheet Tray
16-38	99A0119	4	Wear Strips
16-39	99A1637	1	Label, Tray Option Number
16-40	99A0121	1	Clip, 250 Tray Wear
16-41	99A0126	4	Finger, Autosize
16-42	99A0124	1	Plate, Snap-In
16-43	99A1952	1	Label, Paper Size
16-44	99A1537	1	Knob, Paper Size
16-45	99A0893	1	Restraint, Back 250 Sheet Tray
16-46	99A0127	1	Slider, Autosize 250
NS	99A0286	1	Spring, Backup Roller

4069-XXX Assembly 17: 500 Sheet Tray



Asm- Index	Part Number	Units	Description
17-1	99A0350	1	Sensor, Paper Low
17-2		3	Screw, Auto Comp Mounting PP 99A0263
17-3	99A0405	1	Pick Arm Assembly
17-4	99A0070	2	Pick Roll Assembly
17-5	99A1636	1	Base, 500 Tray
17-6	99A0058	4	Pad, Base 500
17-7	99A0419	1	Spring, Tray Bias
17-8	99A0026	1	Tray Bias Arm Assembly
16-9	99A0288	1	Sensor, Option Pass Thru
17-10	99A1895	1	Restraint, Side 500 Sheet Tray
17-11	99A0292	4	Wear Strips
17-12	99A1829	1	Label, Tray Option Number
17-13	99A1583	1	Plate, 500 Tray Wear
17-14	99A0126	4	Finger, Autosize
17-15	99A0124	1	Plate, Snap-In
17-16	99A1952	1	Label, Paper Size
17-17	99A1582	1	Slider, Autosize 500
17-18	99A0120	2	Restraint Pad
17-19	99A1576	1	Tray Assembly, 500 Sheet
17-20	99A1537	1	Knob, Paper Size
17-21	99A1602	1	Restraint, Back 500 Sheet Tray
17-22	99A1601	1	Latch, Back Restraint
17-23	99A1666	1	Label, Options
17-24	99A1967	1	Board, Tray
17-25	99A0447	1	Shaft, 500 Drive


4069-XXX
Assembly 17: 500 Sheet Tray (continued)



Asm- Index	Part Number	Units	Description
17-26	99A0282	1	Cable, 500 Auto Connect Bottom
17-27	99A1750	1	Wear Plate, Pass Thru
17-28	99A0276	1	Roll Assembly, Drive 500
17-29		2	Screw, Wear Plate Mounting PP 99A0263
17-30	99A0450	1	Retainer, Roller
17-31	99A0451	1	Roller, Skewed Backup
17-32	99A0438	2	Bearing, Drive Roll
17-33	99A0275	1	Spring, Power Takeoff
17-34		3	Screw, Board Mounting PP 99A0263
17-35		1	Retainer, Aligner Assembly PP 99A0267
17-36	99A0280	1	Bearing, Drive Shaft Low
17-37	99A0446	1	Aligner Assembly, Paper
17-38	99A0274	1	Gear, Feed Roll
17-39	99A0063	1	Spring, Switch Activate
17-40	99A0286	1	Spring, Backup Roller
17-41	99A1664	1	Bellcrank, Roller Release
17-42	99A0273	1	Gear, Bevel
17-43	99A0279	1	Bearing, Drive Shaft
17-44	99A0281	1	Cable, 500 Auto Connect Top
17-45	99A1702	1	Stud Assembly, 500 Frame
17-46	99A1645	1	Arm, Paper Out 500
NS	99A0452	4	Washer, Frame Mounting
NS	99A1665	1	Deflector, Base 500
NS	99A1667	2	Bracket, 500 Tray Retention
NS	99A1928	1	Spring, Bellcrank 500 Option Tray
NS	99A1950	1	Tray Feature, Photo Bag Tray Assembly
NS	99A1951	1	Sprint, Photo Bag Transfer


4069-XXX

### **Assembly 18: Duplex**




Asm- Index	Part Number	Units	Description
18-1	99A1674	1	Cover, System Board
18-2	99A0322	1	Main Frame Assembly 250 Duplex
18-2	99A1693	1	Main Frame Assembly 500 Duplex
18-3	99A0324	1	Idler Assembly, Belt Tension
18-4	99A0326	3	Spring, Aligner
18-5	99A0323	3	Guide Assembly, Paper
18-6	99A1675	1	Guide Assembly, Paper
18-7	99A1904	2	Spring, Chassis Ground
18-8		2	Screw, Motor Mount 3 mm PP 99A0413
18-9	99A0328	1	Belt, Motor 114 Gear
18-10	99A0329	1	Pulley, Main Drive 96/54 Gear
18-11	99A0321	1	Motor Assembly, DC Drive
18-12	99A1673	1	Cable, D.C. Motor Tach 250 Duplex
18-13		1	Cam Follower Assembly Kit PP 99A0299
18-14	99A0312	1	Actuator Assembly, Deflector
18-15		2	Screw, Actuator Assembly Mounting PP 99A0413
18-16	99A1130	1	Guide, Return RH Upper 250 Duplex
18-17		2	Screw, Upper Return Guide Mounting PP 99A0413
18-18	99A0340	1	Guide, Return RH Lower 250 Duplex
18-18	99A1680	1	Guide, Return RH Lower 500 Duplex
18-19	99A1579	1	Guide, Upper 500 Duplex
18-20	99A1133	1	Tray Assembly, Jam Removal 250 Duplex
18-20	99A1134	1	Tray Assembly, Jam Removal 500 Duplex
NS		2	Retainer 6 mm - Backup Roll PP 99A0404
NS		2	Screw, M3x6L:G Supradrive PP 99A0413

4069-XXX
Assembly 18: Duplex (continued)




Asm- Index	Part Number	Units	Description
18-21	99A0342	1	Guide, LH Lower Return 250 Duplex
18-21	99A1682	1	Guide, LH Lower Return 500 Duplex
18-22	99A1131	1	Guide, Return LH Upper 250 Duplex
18-23	99A0341	1	Sensor, Exit - Optical
18-24		2	Screw, LH Upper Return Guide Mounting PP 99A0413
18-25	99A1668	1	Base Assembly, w/Tray Bias 250 Duplex
18-25	99A1677	1	Base Assembly, w/Tray Bias 500 Duplex
18-26	99A0316	1	Shaft, Duplex Drive
18-27	99A0315	1	Spring, Duplex Shaft
18-28	99A0325	1	Gear, Pass Thru Idler
18-29	99A0280	1	Bearing, Drive Shaft Low
18-30	99A0311	1	Cable, Auto Connect Bottom
18-31	99A0274	1	Gear, Pass Thru Drive Roll
18-32	99A0310	1	Cable, Auto Connect Top
18-33		4	Screw, Main Frame Assembly Mounting PP 99A0413
18-34	99A0317	1	Gear, Duplex Bevel
18-35	99A0434	1	Pan, System Board Drip
18-36	99A0279	1	Bearing, Drive Shaft
18-37	99A0191	1	Fuse, .8A SB
18-38	99A1669	1	Board, System with Jumper 250/500 Duplex
NS	99A0627	1	Jumper, System Board 250 Duplex
18-39	99A1666	1	Label, Options
18-40		2	Screw, System Board Mounting PP 99A0413
18-41		4	Screw, System Board Cover PP 99A0413
NS	99A1129	1	Roller, Duplex Pass Thru

4069-XXX
Assembly 18: Duplex (continued)




Asm- Index	Part Number	Units	Description
18-42	99A1290	1	Top Cover Assembly, Movable 250 Duplex
18-42	99A1280	1	Top Cover Assembly, Movable 500 Duplex
18-43	99A1634	1	Top Cover Assembly, Fixed 250 Duplex
18-43	99A1679	1	Top Cover Assembly, Fixed 500 Duplex
NS		1	Retainer, 6 mm Top Cover PP 99A0404
18-44	99A0435	1	Guide, Lower Entry 250 Duplex
18-44	99A1691	1	Guide, Lower Entry 500 Duplex
18-45	99A1672	1	Guide Assembly, Paper Decurl
18-46	99A0332	1	Guide, Center Drive Upper
18-47	99A0307	1	Air Plenum
18-48	99A0335	2	Spring, Decurl Shaft
18-49	99A0334	2	Bushing, Decurl Shaft
18-50	99A0952	1	Frame Assembly, 250 Duplex
18-51		3	Screw, Outer Frame PP 99A0413
18-52	99A0330	1	Guide Assembly, Center Drive
18-53		1	Fan Mounting Kit PP 99A0269
		2	o Screw, Fan Mounting M4x30
		2	o Washer, Fan - M4
		2	o Nut, Fan - M4
18-54	99A0308	1	Fan, Cooling Duplex
18-55		2	Retainer, 5 mm Main Drive PP 99A0404
18-56	99A0337	1	Main Drive Assembly
18-57	99A0319	1	Sensor, Input Optical 250 Duplex
18-57	99A1676	1	Sensor, Input Optical 500 Duplex
18-58		4	Retainer, 6 mm Drive Roll PP 99A0404
18-59	99A0336	1	Shaft Assembly, Drive 250 Duplex
18-59	99A1692	1	Shaft Assembly, Drive 3 Roll 500 Duplex
NS	99A1695	1	Shaft Assembly, Drive 2 Roll 500 Duplex
18-60	99A1059	1	Shaft Assembly, Decurl
NS		1	Screw, Tensioner PP 99A0413
NS		2	Retainer, 6 mm Clutch Roll PP 99A0404
NS	99A0058	4	Feet, Duplex Base
NS	99A1164	1	Guide, Debuckle

4069-XXX
Assembly 19: Output Expander




Asm- Index	Part Number	Units	Description
19-1	99A1857	1	Deflector, Upper Redrive Also order 99A0104
19-2	99A0104	1	Spring, Upper Diverter
19-3	99A0369	1	Shaft Assembly, Exit Also order PP 99A0572
19-4	99A0052	1	Shaft Assembly, Lower Exit Also order PP 99A0572
19-5		11	Screw, PP 99A0263
19-6	99A0915	1	Board, Output Expander DC motor
19-7	99A0571	1	Cover, Front Control Board with ESD Brush
19-8	99A1817	1	Tray, Output Expander
19-9	99A1666	1	Label, Options
19-10	99A1689	1	Spring Clutch Assembly
19-11	99A1688	1	Diverter Arm
19-12	99A0482	1	Spring, Output Tray
19-13	99A1784	2	Bracket, Attach
19-14	99A0914	1	Output Expander Assembly, Mechanical Linkage
19-15	99A0372	1	Cover, Left Side
19-16	99A0415	2	Spring, Swing Arm
19-17	99A0481	1	Latch, Output Tray
19-18		2	Shaft Bearing PP 99A0572
19-19	99A0409	1	Level Sensor Bracket
19-20	99A1580	1	Flag, Output Paper Level
19-21	99A0414	1	Sensor, Dual Bin Full

4069-XXX
Assembly 19: Output Expander (continued)




Asm- Index	Part Number	Units	Description
19-22	99A1748	1	Door Assembly, Rear Access
19-23	99A0368	1	Shaft Assembly, Lower Also order PP 99A0572
19-24	99A0363	3	Pulley, Drive
19-25	99A0371	1	Cover, Right Side
19-26	99A0361	1	Belt, 160 Gear
19-27	99A0362	1	Arm Assembly, Belt Idler
19-28	99A0364	1	Spring, Belt Tensioner
19-29	99A0351	1	Sensor, Output Expander Pass Thru
19-30	99A0913	1	Shaft Assembly, Middle 40T Also order PP 99A0572
19-31	99A0912	1	Frame Assembly

4069-XXX Assembly 20: Envelope Feeder



Asm- Index	Part Number	Units	Description
20-1	99A0389	1	Paper Weight Assembly
20-2	99A1694	1	Guide, Edge
20-3	99A1696	1	Cover, Top
20-4	99A0485	1	Sensor, Envelope Pass Thru
20-5	99A0393	1	Clutch, Restraint/Gear
20-6	99A1697	1	Cover, Right Side
20-7	99A0390	1	Support, Slide Out
20-8	99A0488	7	Roller, Support
20-9	99A0382	1	Motor, Stepper D.C.
20-10	99A1666	1	Label, Options
20-11	99A0388	1	Switch, Envelope Out
20-12	99A1700	1	Board Assembly, Electronic Control
NS		6	Screw, Top/Motor/Board
NS	99A0484	1	Belt, Gear Drive
NS	99A0491	1	Bracket, Stack Limiter
NS	99A0400	1	Spring, Restraint Roll Shaft
NS	99A0489	1	Spring, Latch Return
NS	99A0487	1	Flag, Envelope Out Sensor


4069-XXX
Assembly 20: Envelope Feeder (continued)



Asm- Index	Part Number	Units	Description
20-13		1	Gear Kit, PP 99A0271
		1	o Gear, Feed
		1	o Gear, Master Cam
		1	o Gear, Drive Roll Shaft
		3	o Gear, Master/Feed Kick
		2	o Gear, Drive Idler
		1	o Gear, Comp Drive/Clutch
		1	o Gear, Kick Roll Connect
		1	o Gear, Kick CNCT Idler
		1	o Gear, Feed Shaft Right
		1	o Gear, Drive Idler Rear
20-14	99A1698	1	Cover, Left Side
NS		1	Retainer, 4 mm PP 99A0404
NS		3	Retainer, Clip 5 mm Shaft PP 99A0404
NS		2	Retainer, 6 mm PP 99A0404
NS		3	Retainer, 7 mm Shaft PP 99A0404
NS	99A0384	1	Shaft, Drive Pressure Roller
NS	99A0385	1	Cable, Auto Connect Front
NS	99A0494	1	Spring, Cam Clutch
NS	99A0427	1	Label, Envelope Orientation Icon
NS	99A0469	1	Deflector Guide
NS	99A1699	1	Guard, Pass Through Sensor

4069-XXX


# Assembly 21: High Capacity Feeder



Asm- Index	Part Number	Units	Description
21-1	99A0660	1	Frame, Printer Support Frame 2
21-2		3	Screw, Printer Support 2 Frame Mounting PP 99A0675
21-3	99A0698	2	Clamp, Feed Frame
21-4		4	Screws, Feed Frame Clamp PP 99A0675
21-5	99A0691	2	Bearing, Nyliner Leadscrew Top
21-6	99A0656	1	Cover, Side
21-7	99A0681	4	Strip, Wear
21-8	99A1818	1	Strip, Wear Dimple
21-9	56P1735	1	Deflector Assembly Front
21-10		3	Screw, Deflector Mounting 8-18 x 7/8 inch PP 99A0675
21-11	99A1829	1	Label, Tray Option Number
21-12	99A0662	2	Transfer Lead Screw Assembly
21-13	99A0716	1	Bearing, Leadscrew Bottom
NS		6	Washer, Printer Support Frame 2 Star PP 99A0677
NS		6	Nut, Printer Support Frame 2, 8-32 Hex PP 99A0676


4069-XXX

# **Assembly 21: High Capacity Feeder (continued)**




Asm- Index	Part Number	Units	Description
21-14		4	Nut, 6-32 Hinge Mounting PP 99A0676
21-15		4	Washer, Hinge Mounting Flat PP 99A0677
21-16		4	Washer, Hinge Mounting Star PP 99A0677
21-17	99A0657	2	Hinge, Door
21-18	99A0655	1	Door Assembly, Front
21-19	99A0658	2	Magnet, Door
21-20	99A0650	1	Frame Assembly
21-21	99A0661	1	Tray Assembly, Elevator
21-22	99A1806	1	Card Assembly, 2000 Option Control
21-23		4	Washer, Card Assembly Mounting PP 99A0677
21-24		4	Screw, Card Assembly Mounting PP 99A0675
21-25	99A0392	1	Kit, Door Switch Spring and Bumper
21-26		1	Washer, Door Switch Spring Mounting PP 99A0677
21-27		1	Nut, Door Switch Spring Mounting PP 99A0676
NS	99A0690	1	Cable, Optical Sensor

4069-XXX
Assembly 21: High Capacity Feeder (continued)




Asm- Index	Part Number	Units	Description
21-28	99A0188	3	Guide, Rear Paper with retainer arm Use with 99A0219
21-29		6	Screw, Top Frame Mounting PP 99A0675
21-30	99A0219	1	Frame Assembly, Top with labels
21-31		2	Screw, Top Frame Clamp Mounting PP 99A0675
21-32		2	Washer, Top Frame Clamp PP 99A0677
21-33	99A0719	1	Clamp, Top Frame Mounting
21-34		2	Nut, Base Mounting PP 99A0676
21-35		2	Washer, Base Mounting PP 99A0677
21-36		2	Screw, Base Mounting PP 99A0675
21-37	99A0663	1	Pulley, Idler
21-38	99A0664	1	Belt, Drive
21-39	99A1807	1	Cable, AC Internal Wiring
21-40		2	Nut, 2-56 Lower Limit Switch Mounting PP 99A0676
21-41	99A0653	1	Switch, Lower Limit Microswitch
21-42		2	Nut, Power Supply Ground PP 99A0676
21-43		4	Washer, Motor Plate Mounting PP 99A0677
21-44	99A1808	1	Cord, AC External Jumper
21-45		2	Nut, Power Supply Cover PP 99A0676
21-46	99A0714	1	Cover, Power Supply
21-47		2	Screw, Power Supply Board Mounting PP 99A0675

4069-XXX
Assembly 21: High Capacity Feeder (continued)




Asm- Index	Part Number	Units	Description
21-48		2	Washer, Power Supply Board PP 99A0677
21-49	99A0667	1	Power Supply Board
21-50	99A0715	1	Cable, Low Voltage Power Supply
NS	99A0684	1	Cable, HCIT-14Pin Flex
21-51	99A0685	1	Bushing
21-52		2	Nut, 2-56 Paper Low Switch Mounting PP 99A0676
21-53	99A0654	1	Switch, Paper Low
21-54	99A0651	1	Sensor Assembly, Paper Out/Upper Limit
21-55		3	Screw, Printer Support 1 Frame Mounting PP 99A0675
NS		6	Washer, Printer Support Frame 1 Star PP 99A0677
NS		6	Nut, Printer Support Frame 1 8-32 Hex PP 99A0676
NS		10	Screw, Door to Door Frame Mounting PP 99A0675
21-56	99A0659	1	Frame, Printer Support 1
21-57	99A0695	1	Parts Kit, Paper Size Switch Assembly including cable, switch, lock washer, nut and knob
21-58		2	Washer, Sensor Bracket Mounting PP 99A0677
21-59		2	Screw, Sensor Bracket Mounting PP 99A0675

4069-XXX
Assembly 21: High Capacity Feeder (continued)




Asm- Index	Part Number	Units	Description
21-60		3	Screw w/washer, Motor Mounting PP 99A1793
21-61		3	Nut w/lockwasher, Drive Pulley Plate PP 99A1794
21-62	99A1795	1	Motor Assembly, DC
21-63		4	Foot, Stabilizer PP 99A0672
21-64		4	Mounting Feet PP 99A0687
21-65	99A1796	1	Belt, DC Motor Drive
21-66	99A1797	1	Idler Pulley, Belt Tension
21-67	99A1798	1	Plate, Drive Pulley
21-68	99A1799	1	AC Receptacle, Lower AC
21-69	99A1800	1	Pulley, Drive
21-70	99A1801	1	Retainer, C-Clip
21-71	99A1802	1	AC Receptacle, Upper AC
21-72	99A1803	1	Cover, Top LVPS
21-73	99A1804	3	Nut w/lockwasher, Top LVPS Cover Mounting
21-74	99A1804	1	Nut w/lockwasher, Top LVPS Cover Mounting
21-75	99A1805	1	Grommet, Top LVPS Cover

# **Assembly 21: High Capacity Feeder (continued)**




Asm- Index	Part Number	Units	Description
21-76	99A0281	1	Cable, 250 Auto Connect
21-77	99A0279	1	Bearing, Drive Shaft
21-78	99A0273	1	Gear, Bevel
21-79		2	Screw, Frame Mounting PP 99A0263
21-80	99A0276	1	Roll Assembly, Drive 250 Option
21-81	99A0451	1	Roll, Skew Backup
21-82		1	Retainer, Roller PP 99A0267
21-83		2	Screw, Wear Plate Mounting PP 99A0675
21-84	99A0277	1	Plate Wear, Pass Thru
NS	99A0286	1	Spring, Backup Roller
21-85	99A0445	1	Stud Assembly, 250 Frame
21-86	99A0280	1	Bearing, Drive Shaft Low
21-87	99A0275	1	Spring, Power Takeoff
21-88	99A0272	1	Shaft, 250 Drive
21-89	99A0446	1	Aligner Assembly, Paper
21-90		1	Retainer, Aligner Assembly PP 99A0267
21-91	99A0274	1	Gear, Feed Roll
21-92	99A0278	1	Bellcrank, Roller Release
21-93	99A1967	1	Card Assembly, 2000 Tray Option
21-94		3	Screw, 2000 Tray Option Card Mounting PP 99A0263

4069-XXX
Assembly 21: High Capacity Feeder (continued)




Asm- Index	Part Number	Units	Description
21-95		3	Screw, Auto Comp Assembly Mounting PP 99A0263
21-96	99A1055	1	Arm Assembly, Pick 2000
21-97	99A0070	2	Roll Assembly, Pick
21-98	99A0692	1	Base, 2000 Option
21-99		1	Screw, Deflector Mounting PP 99A0263
21-100	99A0678	1	Deflector, Base
21-101	99A0288	1	Sensor, Pass Thru
21-102	99A1812	1	Label, Tray Option Number
21-103	99A1666	1	Label, Options
21-104		4	Washer, Bracket 250 Frame Retention Mounting PP 99A0677
21-105		4	Screw, Bracket 250 Frame Retention Mounting PP 99A0263
21-106	99A0679	2	Bracket, 250 Frame Retention
NS	99A0717	1	Cable, Paper Low Switch
NS	99A0720	1	Cable, Lower Limit Switch

4069-XXX Assembly 22: Kiosk - Vertical Paper Adapter




Asm- Index	Part Number	Units	Description
22-1	99A0231	1	Bail, Support
22-2	99A1646	1	Arm Assembly, Pivot
22-3	99A1819	1	Mounting, Frame Assembly
22-4		12	Retainer PP 99A0240
22-5		16	Screws PP 99A0234
22-6	99A1705	1	Gear, Idler
22-7	99A1704	2	Gear, Idler
22-8	99A0197	1	Shaft, Drive Rear
22-9	99A0079	1	Tray Assembly, Backup Roller
22-10		3	Parts, Pulley PP 99A0208
22-11	99A0087	6	Spring, Backup Roller
22-12	99A0086	6	Roller, Backup
22-13	99A1706	1	Tray Assembly, Drive Roller
22-14	99A0125	1	Frame Assembly, Right Side
22-15	99A0232	1	Cover, Right
22-16	99A1820	2	Belt, 185G
22-17	99A0226	1	Guide, Paper Exit
22-18	99A0122	2	Shaft Assembly, Drive Roller
22-19	99A0137	1	Frame Assembly, Left Side
22-20	99A0088	1	Cover, Backup Tray
22-21	99A0085	1	Tray, Backup Roller

4069-XXX Assembly 23: Kiosk - Horizontal Paper Adapter




Asm- Index	Part Number	Units	Description
23-1	99A0231	1	Bail, Support
23-2	99A1646	1	Arm Assembly, Pivot
23-3	99A1819	1	Mounting, Frame Assembly
23-4		12	Retainer PP 99A0240
23-5		15	Screws PP 99A0234
23-6	99A1705	1	Gear, Idler
23-7	99A1704	2	Gear, Idler
23-8	99A0197	1	Shaft, Drive Rear
23-9	99A0079	1	Tray Assembly, Backup Roller
23-10		3	Parts, Pulley PP 99A0208
23-11	99A0087	6	Spring, Backup Roller
23-12	99A0086	6	Roller, Backup
23-13	99A1707	1	Tray Assembly, Drive Roller
23-14	99A0907	1	Frame Assembly, Right Side
23-15	99A0232	1	Cover, Right
23-16	99A1820	2	Belt, 185G
23-17	99A0122	2	Shaft Assembly, Drive Roller
23-18	99A0906	1	Frame Assembly, Left Side
23-19	99A0088	1	Cover, Backup Tray
23-20	99A0085	1	Tray, Backup Roller

4069-XXX
Assembly 24: High-Capacity Output Stacker




Asm- Index	Part Number	Units	Description
24-1	99A1748	2	Door Asm, Rear Access
24-2	99A1785	4	Latch, Rear Door
24-3	99A1783	1	Frame, Right
24-4	99A1778	2	Pulley, Output Tray
24-5	99A1782	2	Shaft, Pulley
24-6	99A1790	2	Guide, Output Tray
24-7	99A1779	2	Spring, Output Tray
24-8	99A1746	1	Cover, Right
24-9	99A1747	1	Cover, Front
24-10	99A1701	1	Tray Asm, Output
24-11	99A1781	1	Frame, Left
24-12	99A1666	1	Label, Options
24-13	99A1745	1	Cover, Left
24-NS	99A1751	1	Switch Asm, Tray Sensing
24-NS	99A1777	1	Flag, Tray Sensing Switch
24-NS	99A1780	2	Gear, Damping
24-NS	99A1744	2	Kit, High-Capacity Output Stacker

4069-XXX
Assembly 24: High-Capacity Output Stacker (cont'd)




Asm- Index	Part Number	Units	Description
24-14	99A0107	2	Deflector, Upper Also order 99A0104
24-15	99A0104	2	Spring, Upper Diverter
24-16	99A0369	1	Shaft Asm, Exit Upper Stacker Asm
24-17	99A0052	1	Shaft Asm, Stacker Lower Exit Upper Stacker Asm
24-18		12	Bearings, Shaft PP 99A0572
24-19	99A1749	2	Board Asm, High-Capacity Output Stacker
24-20		31	Screws, PP 99A0263
24-21	99A1688	1	Arm, Diverter
24-22	99A1689	1	Clutch Asm, Output Stacker
24-23	99A1784	2	Bracket, Attach
24-24	99A0415	2	Spring, Swing Arm
24-25	99A0914	2	Drive Asm, Output Stacker DC Motor
24-26	99A0409	1	Bracket, Dual Sensor Mounting Upper Stacker Asm
24-27	99A1613	1	Flag, Bin Full Dual Sensor Upper Stacker Asm
24-28	99A0414	1	Sensor Asm, Bin Full Dual Upper Stacker Asm
24-NS	99A1690	1	Belt, 95G Lower Stacker Asm

4069-XXX
Assembly 24: High-Capacity Output Stacker (cont'd)



Asm- Index	Part Number	Units	Description
24-29	99A0913	2	Shaft, 40T Middle Output Stacker
24-30	99A0368	2	Shaft Asm Lower
24-31	99A0363	6	Pulley, Drive
24-32	99A0361	1	Belt, 160G Upper Stacker Asm
24-33	99A0362	1	Arm Asm, Belt Idler
24-34	99A0364	2	Spring, Belt Tensioner
24-35	99A1791	1	Stacker Asm, Paper Path Lower
24-35	99A1792	1	Stacker, Asm Paper Path Upper
24-36	99A0351	2	Sensor, Stacker Passthru
24-NS	99A1751	1	Switch Asm
24-NS	99A0462	1	Packet Grease, IBM #23
24-NS	99A0627	1	Jumper, 2 pin (Use with 99A1749)


4069-XXX Assembly 25: 5-Bin Mailbox



Asm- Index	Part Number	Units	Description
25-1	99A1512	1	Cover, Redrive Cap
25-2	99A1710	1	Cover, Wire
25-3	99A1711	1	Cover, Top Bin
25-4	99A1785	2	Latch, Rear Access Door
25-5	99A0104	1	Spring, Upper Diverter
25-6	99A1714	1	Door, Rear Access
25-7	99A1723	4	Shaft Asm, Drive
25-8	99A1724	1	Shaft Asm, Drive W/Gear
25-9	99A1708	1	Cover, Right Side
25-10	99A1725	1	Packet, Drive Shaft Bushing
25-11	99A1742	2	Sensor, 5-Bin Mailbox Passthru
25-12	99A1712	5	Tray, Paper Cap
25-13	99A1739	1	Bracket Asm, Bail Attach w/Brush
25-14	99A1743	1	Kit, 5-Bin Mailbox Asm
25-15	99A1666	1	Label, Options
25-16		1	Bail, order 99A1743, 5-Bin Mailbox Asm Kit
25-17	99A1713	5	Support, Paper Tray
25-18	99A1687	5	Stop Asm, Paper Tray
25-19	99A1735	5	Flag, Bin Full
25-20	99A1737	5	Sensor, Dual Paper Height
25-21	99A1736	5	Cable, Dual Sensor
25-22	99A1718	1	Cable Asm, Lower Auto Connect
25-23	99A1716	1	Drive Asm, Main DC Drive
25-24	99A1740	1	Board Asm, 5-Bin Mailbox System
25-25	99A1726	1	Frame Asm, Left w/Clutch Asm
25-26	99A1786	1	Gear, Drive
25-27	99A1719	1	Cable Asm, Upper Auto Connect
25-28		12	Screw, Board Mounting PP 99A0263
25-29	99A1709	1	Cover, Left Side

4069-XXX

# Assembly 25: 5-Bin Mailbox (continued)



Asm- Index	Part Number	Units	Description
25-30	99A1741	4	Spring, Diverter
25-31	99A1727	1	Frame Asm, Right Side
25-32	99A1728	4	Cam, Diverter Actuator
25-33	99A1731	4	Spring, Diverter Actuator
25-34	99A1729	4	Latch, Diverter Actuator
25-35	99A1730	4	Arbor, Diverter Actuator
25-36	99A1789	4	C-Clip
25-37	99A1720	1	Bracket, Attach
25-38	99A1732	4	Solenoid, Diverter
25-39	99A1738	5	Deflector, Paper Exit w/Brush
25-40	99A1722	4	Deflector, Paper
25-41	99A1787	4	Deflector
25-42	99A1721	1	Deflector, Paper Top Bin
25-NS	99A1734	1	Spring, Static Ground
25-NS	99A0462	1	Grease Packet, IBM #23
25-NS	99A1715	1	Roller Asm, Rear Access Door
25-NS	99A1717	1	Gear, Drive
25-NS	99A1788	1	Retainer, R-Ring

4069-XXX Assembly 26: Options

Asm- Index	Part Number	Units	Description
26	99A1752	1	4MB SDRAM DIMM
26	99A1753	1	8MB SDRAM DIMM
26	99A1754	1	16MB SDRAM DIMM
26	99A1755	1	32MB SDRAM DIMM
26	99A1756	1	64MB SDRAM DIMM
26	99A1773	1	128MB SDRAM DIMM
26	99A1757	1	2MB Flash DIMM
26	99A1758	1	4MB Flash DIMM
26	99A1759	1	8MB Flash DIMM
26	99A1774	1	16MB Flash DIMM
26	99A1886	1	DIMM, Font Traditional Chinese
26	99A1887	1	DIMM, Font Simplified Chinese
26	99A1885	1	DIMM, COS (supports Chinese fonts)
26	99A1126	1	SIMM, Bar Code
26	99A1089	1	SIMM, Prescribe 5/4/2 Flash
26	99A1884	1	SIMM for IPDS and SCS/Tne
26	99A0459	1	Hard Disk, with Control Board 2.1GB
26	99A1084	1	SIMM, IPDS 5/4/2 Flash
26	99A0629	1	Adapter Card, SES for SCS
26	13A0296	1	Cable, Twinax
26	13A0297	1	Cable, Coax
26	99A0545	1	Adapter, Serial
26	13A0298	1	Cable, Serial
26	99A0467	1	Board, Parallel Port Adapter
26	99A0923	1	Board, USB/Parallel Port
26	99A1859	1	SIMM, Image Quick Tiff
26	99A1031	1	SIMM, Image Quick Web

4069-XXX
Assembly 26: Options (continued)

Asm- Index	Part Number	Units	Description
26	99A1890	1	Tray Assembly, 250 Special Media 010/212/414/616/41b/41l/23v/23e
26	99A1647	1	Rib Assembly, 250 Special Media Tray 010/212/414/616/41b/41l/23v/23e
26	99A1654	1	Tray, Universal Adjustable 250 Sheet
26	99A0910	1	Cartridge, Empty Shipping (2)
26	99A0909	1	Cartridge, Empty Shipping (1)
26	99A0863	1	Stacking Device, Integrated Label/Letter
26	99A0864	1	Stacking Device, Integrated Label/Letter
26	99A0865	1	Stacking Device, Legal Label
26	99A0799	1	Drive, Forms HD 2.1GB or larger
26	99A1605	1	Kit, Cap/Stack Bails 500
26	99A0945	1	Kit, Paper Stacking Arm
26	99A1830	1	Marknet N2001e 10/100 ethernet
26	12G1696	1	Marknet N2002e 10base2/10baseT
26	12G1697	1	Marknet N2000t 4/16
26	99A0560	1	Adapter, Omnibus INA Card
26	99A1889	1	Paper Presentator, Front 010/212/23v/23e/ 41e/0ln/2ln
26	99A1950	1	Tray Feature, Photo Gab Tray Assembly 25v/25e
26	99A1951	1	Spring, Photo Bag Transfer 25v/25e
26	56P1101	1	Cable Assembly, 6' Parallel A-C
26	56P0161	1	Cable Assembly, SER+PAR 1284-C INA
26	56P0162	1	Cable, Parallel 1284 C-B Adapter

4069-XXX Assembly 27: Miscellaneous

Asm- Index	Part Number	Units	Description
27	99A1633	1	Parts Packet, Screws
27	99A0585	1	Parts Packet, Contact Kit
27	99A0267	1	Parts Packet, Retainers
27	99A0268	1	Parts Packet, Springs Paper Feed
27	99A0269	1	Parts Packet, Duplex Option Fan Mounting
27	99A0299	1	Parts Packet, Duplex Option Cam Follower Assembly
27	99A0271	1	Parts Packet, Envelope Option Gears
27	99A0404	1	Parts Packet, Retainers Envelope Option
27	99A0413	1	Parts Packet, Screws Duplex
27	99A0572	1	Parts Packet, 500 Sheet Feeder Option Shaft Bearings
27	99A0577	1	Parts Packet, Cable Ties (10 each)
27	99A0675	1	Parts Packet, Screws High Capacity Feeder
27	99A0676	1	Parts Packet, Nuts High Capacity Feeder
27	99A0677	1	Parts Packet, Washers High Capacity Feeder
27	99A0083	1	Parts Kit, Multipurpose Tray
27	99A0512	1	Parts Kit, Charge Roll Link Asm, Left Side
27	99A0513	1	Parts Kit, Charge Roll Link Asm, Right Side
27	99A0186	1	Parts Kit, Erase Lamp/Lens
27	99A0702	2	Printer Stand Caster, Non Locking
27	99A0703	2	Printer Stand Caster, Locking
27	99A0704	1	Printer Stand Grommet, Wire
27	99A0705	2	Printer Stand Lock, Cam
27	99A0706	1	Printer Stand Storage Shelf
27	99A0707	1	Printer Stand Door Assembly, Cabinet
27	99A0710	1	Printer Stand Filler, Rear Top Piece
27	99A0711	1	Printer Stand Table Assembly, Large
27	99A0712	1	Printer Stand Table Assembly, Small

4069-XXX
Assembly 27:Miscellaneous (continued)

Asm- Index	Part Number	Units	Description
27	99A0208	1	Parts Packet, Pulley - Kiosk
27	99A0234	1	Parts Packet, Screws - Kiosk
27	99A0394	1	Grease Packet, Nyogel 744
27	99A0462	1	Grease Packet, IBM 23
27	99A1852	1	Packaging, 4069 250/250 printer
27	99A1853	1	Packaging, 4069 500/250 printer
27	99A1854	1	Packaging, 4069 500/500 printer
27	99A1855	1	Packaging, 4069 500/500 plus 500 printer
27	99A0240	1	Parts Packet, Retainer